

HISTORY KEPT YES <input type="checkbox"/> NO <input checked="" type="checkbox"/>	ILLINOIS HIGHWAY INFORMATION SYSTEM STRUCTURE INFORMATION AND PROCEDURE MANUAL		
NBIS REQUIRED YES <input type="checkbox"/> NO <input checked="" type="checkbox"/>	ITEM NAME FLOOD BASE Q		ITEM NO. 71F PAGE 1 of 1 EFF. DATE 07/01/02
	ISIS		MMIS
RESPONSIBLE FOR UPDATE	Central Bureau of Bridges & Structures		N/A
STRUCTURES	Local	State	N/A
UPDATE SCREENS	(4) Misc Waterway Info	(5) Waterway Data	N/A
INQUIRY SCREENS	(3) Inventory Data 3 (22) Waterway Info		(1) Inventory Data 3 of 3 (18) Waterway

DESCRIPTION AND PURPOSE OF ITEM

This item indicates the magnitude of the 100 year frequency flood at the structure. It is to be expressed in cubic feet per second (cfs) and rounded to the nearest foot.

CODE AND SCREEN ENTRY INSTRUCTIONS

A seven-digit field, right justified.

Enter the value in terms of cubic feet rounded to the nearest whole number.

Fill leading spaces with zeros as appropriate.

EXAMPLES:

Flood Base Q

Enter

850,010.3 cfs

0850010